

MULTI-FUNCTION

Back Height Adjustment

Turn knob counter-clockwise to loosen, lift or lower chair back to desired position and retighten for critical lumbar curve positioning.

Back Angle Adjustment

While seated, pull paddle up, when desired angle found push paddle down to lock. Back will free float in the paddle up position.

Pneumatic Height Adjustment

To lower, lift paddle while seated. To raise, lift paddle with your weight off seat.

Infinite Seat Angle Adjustment with 6 degree Forward Tilt

To change seat angle, pull paddle up while seated, push paddle down to lock when desired angle is achieved. Seat can rock.

Forward Tilt

Lean back in chair and roll or pull lever forward for forward tilt, push or roll lever backward for flat position during rocking. Attention: lever can only be moved when in a rear rocking position.

Tension Knob

Turn clockwise to increase tension, turn counter-clockwise to decrease tension.

