

SWIVEL TILTER

Back Angle Adjustment

While seated, pull paddle up, when desired angle found push paddle down to lock. Back will free float in the paddle up position.

Pneumatic Height & Tilt Rock Lock

To lower, lift paddle while seated. To raise, lift paddle with your weight off seat. The lever pushes in towards control to lock in the neutral position. Pull lever out to rock free.

Tension Knob

Turn clockwise to increase rocking tension, turn counter-clockwise to decrease tension.

